

REGENCY TWIN - BANNER STAND user instructions

1



REGENCY TWIN Banner stand kit includes:
Double cassette silver Aluminium base,
Telescopic pole set
Double top rail retaining clip
Printed graphic panels
Carry bag

2



Twist the telescopic pole to unlock each section. Fully extend the bottom two sections to maximum length. Extend the top so the height markings line up at ~2130mm. Twist again to lock in position.

Insert the top rail retaining clip on the top of the pole

3



Insert extended pole into the base.

Carefully pull the graphic from the top of the silver base. Lean the banner stand backwards and extend the roll up banner toward you until fully extended.

4



Carefully pull up the second side toward you, until fully extended.

Hook the top rail of the banner stand over the retaining clip.

5



Make any final adjustments to the height by twisting and locking the telescopic pole.

6



The exhibition display banner stand is now fully assembled and ready for use.

7



To lower the roll up banner, gently feed the graphics into the base - one side at a time. **Do not let go of the graphics until fully retracted into the base.**

8



Your portable banner stand can be easily transported in the supplied protective carry bag.

How to care for your Graphics

When cared for correctly, your graphics have the potential to give excellent service for a considerable time.

1. Never fold or bend your graphics
2. Use the supplied case for transportation
3. Do not expose graphics to water / moisture
4. Do not expose graphics to excessive heat
5. Do not expose graphics to direct sunlight
6. Store in dry temperature environment
7. Store at room temperature for 48 hrs before use to avoid curling