

## MOBI FOLDING DISPLAY SCREENS User Instructions



1




Remove the folding panels from the packaging and stand upright on a flat surface

2



Hold the end panel and pull outward to unfold the panels

3



All Mobi 6 panles and above have an additional centre stabilising foot for extra stability

When in position fit the stabilising feet to the panels by slotting into place and tightening until the foot is securely in place

4

✓ Correct



✗ Incorrect



Please ensure the screens are folded together correctly to ensure they are stored safely and avoid damage to the hinges