

Switch Banner Stand





Scan our QR code to view the full assembly video



Step 1
Position the round base on the floor and take the bottom pole section which has a thread. Twist the pole to tighten to the circular base.
Make sure the small magnet is facing forwards.



Step 2
Take the second half of the pole and slot into the already secured bottom pole section.



Step 3
At the top of the pole you'll find a black moulding which fits into the top channel of the printed banner. Slide the moulding to the centre of the printed panel so the display sits central.



Step 4
Finally, position the bottom of the printed panel so the banner connects with the magnet at the bottom of the pole. This will attach and hold the banner in place.



Switch

SWITCH BANNER 850

- Pole and base hardware & full colour graphics panel.
- Strong aluminium pole with black powder coated steel base.
- Choice of media; 180 micron Spotlight film or 600 micron block fabric.
- 3 Year Manufacturer's Guarantee against banner hardware.
- Quick interchangeable graphic panels.
- Easy to use & assemble.
- Digitally printed in house
- Dispatched in 48 hours from receipt of order and artwork.

SWITCH BANNER, DESIGNED & MANUFACTURED IN THE UK
www.go-displays.co.uk
www.rapid.com